


Introduction to bx Program (BANAL)

To accompany Exercise 2

C.T. Russell

April 9, 2008

Front Page: Getting Started




- The first thing you need is a dataset. Pull down the menu from the file button and select "Example"
- In this exercise get the "Shock Io Beta $M/Mc=0.56$ " example and then use the shock coplanarity option under the rotate button to place the data in the shock coordinate system
- Next pull down the Spectra menu and select Spectrum A

Fourier Analysis: A primer



- Fourier analysis decomposes a signal into a series of orthogonal sine and cosine waves of frequency and to the fundamental of the data set to the Nyquist frequency, half the sample rate.
- N points in a time series can produce N Fourier amplitudes.
- A fundamental assumption of Fourier analysis is that the time series REPEATS and ad infinitum. Thus a slope turns into a saw tooth wave with frequency content over the entire frequency band.
- To remove this power detrending is recommended. Remove the slope!
- A power spectrum is constructed from the squared amplitudes of the cosine and sine waves (a and b coefficients). It is normalized so that the square root of the integral under the power spectral density curve is the root mean square amplitude.
- When you have 2 or 3 signals you can define the coherence and the phase difference between the time series
- With multiple signals you can define spectral matrices that give the in phase and out of phase power
- A minimum variance analysis or principal axis analysis on the cospectrum (in phase power) gives the direction of propagation of waves. A different but equivalent process works for circularly polarized waves using the quaspectrum.

Detrending



- Detrending removes the slope in the field that will add uninformative power spectral density to the spectrum
- Linear and quadratic detrending are available. Always keep the average field if you are going to do wave analysis
- Remember to push the apply button


Power Spectral Density Calculation





- When we choose a time interval after we have selected 'Spectra', a power spectral density plot will be displayed
- We initially show a log-log plot but a semi log plot can be selected from the options list

Options

- “Options” allow you to determine the coherence between pairs of signals; their phase difference, or both at the same time
- Sum of power allows you to combine power from different sensors. In particular you can calculate the power in the field strength (compressional power) and then subtract it from the summed power to obtain the transverse wave power. Regular power brings you back to the original display.
- Band width allows you to smooth the spectrum by adding up the power over a broader (sliding) window.
- W/O grid removes the grid.
- Number of spectral decades enables you to tailor the plot. I prefer log-log plots to have square decades.
- Frames allows you to plot a single frame of the 2 x 2 panel





Options continued



- Remember to push the “Use the values above” button.
- Remember to push the “Apply” button.

Coherence and Phase



- When you select coherence or phase you get a 2 by 2 display. The average coherence has some meaning but the average phase does not
- Linear frequency displays sometimes are helpful
- Coherence sometimes brings out relationships in otherwise featureless spectra


Wave Analysis

<p>--- Data Interval ---</p> <p>Start: 78 240 AUG 28 00:08:00.333 Stop : 78 240 AUG 28 00:08:55.744</p> <p>--- Frequency Interval(Hz) ---</p> <p>min: 0.09013 max: 0.12619 Wgtd Freq: 0.10639 Norm Freq: 0.31432</p> <p>--- Field Data Average ---</p> <p>BX: 14.594 BY: -13.067 BZ: -10.176 BT: 22.195</p>		<p>--- Power Spectra Parameters ---</p> <p>Power Spectra Trace (nT²) = 3.7183986 Trace Amplitude (nT) = 1.9283149 Compressional Power (nT²) = 1.3911248 Compressional Amplitude (nT) = 1.1794596 Compressional Fraction Amplitude = 0.05314 Total Fraction Amplitude = 0.06688 Compressional Ratio = 0.37412</p>																																																																																																					
<p>--- Real and Imaginary Power Spectral Matrices (nT²)---</p> <table border="1"> <tr> <th colspan="3">RP</th> <th colspan="3">IP</th> </tr> <tr> <td>0.0577006</td><td>-0.1638372</td><td>-0.1065867</td> <td>0.0000000</td><td>0.0841499</td><td>-0.1632216</td> </tr> <tr> <td>-0.1638372</td><td>1.7616366</td><td>0.3287636</td> <td>-0.0841499</td><td>0.0000000</td><td>1.7939365</td> </tr> <tr> <td>-0.1065867</td><td>0.3287636</td><td>1.8990614</td> <td>0.1632216</td><td>-1.7939365</td><td>0.0000000</td> </tr> </table> <p>--- Transformed Values of Real and Imaginary Power Spectral Matrices ---</p> <table border="1"> <tr> <th colspan="3">RP'</th> <th colspan="3">IP'</th> </tr> <tr> <td>2.1825457</td><td>0.0000001</td><td>-0.0000000</td> <td>0.0000000</td><td>-1.8032761</td><td>-0.0003891</td> </tr> <tr> <td>0.0000001</td><td>1.4968913</td><td>-0.0000000</td> <td>1.8032761</td><td>0.0000000</td><td>-0.0113041</td> </tr> <tr> <td>-0.0000000</td><td>-0.0000000</td><td>0.0389624</td> <td>0.0003891</td><td>0.0113041</td><td>0.0000000</td> </tr> <tr> <th colspan="3">RM'</th> <th colspan="3">IM'</th> </tr> <tr> <td>2.1462443</td><td>0.1533551</td><td>-0.0130047</td> <td>0.0000001</td><td>1.8033111</td><td>-0.0000000</td> </tr> <tr> <td>0.1533552</td><td>1.5331080</td><td>-0.0033946</td> <td>-1.8033111</td><td>0.0000000</td><td>0.0000000</td> </tr> <tr> <td>-0.0130047</td><td>-0.0033946</td><td>0.0390467</td> <td>0.0000000</td><td>0.0000000</td><td>-0.0000000</td> </tr> </table>		RP			IP			0.0577006	-0.1638372	-0.1065867	0.0000000	0.0841499	-0.1632216	-0.1638372	1.7616366	0.3287636	-0.0841499	0.0000000	1.7939365	-0.1065867	0.3287636	1.8990614	0.1632216	-1.7939365	0.0000000	RP'			IP'			2.1825457	0.0000001	-0.0000000	0.0000000	-1.8032761	-0.0003891	0.0000001	1.4968913	-0.0000000	1.8032761	0.0000000	-0.0113041	-0.0000000	-0.0000000	0.0389624	0.0003891	0.0113041	0.0000000	RM'			IM'			2.1462443	0.1533551	-0.0130047	0.0000001	1.8033111	-0.0000000	0.1533552	1.5331080	-0.0033946	-1.8033111	0.0000000	0.0000000	-0.0130047	-0.0033946	0.0390467	0.0000000	0.0000000	-0.0000000	<p>--- Principal Axis analysis ---</p> <table border="1"> <tr> <th colspan="3">EIGENVECTORS</th> <th>EIGENVALUES</th> </tr> <tr> <td>-0.087</td><td>0.634</td><td>0.768</td> <td>2.18255</td> </tr> <tr> <td>0.040</td><td>-0.768</td><td>0.639</td> <td>1.49689</td> </tr> <tr> <td>0.995</td><td>0.087</td><td>0.042</td> <td>0.03896</td> </tr> </table> <p>ANGLE BK: 54.019 KK: 0.357</p> <p>--- Joe Means Analysis (JGR 77,5551 1972) ---</p> <p>Propagation: 0.995 0.091 0.047 Angle: 54.366 LinearVariance: 0.860 -0.279 -0.428 Angle: 21.454</p> <p>--- Born-Wolf Analysis (JGR 75,5444 1970) ---</p> <table border="1"> <tr> <th></th> <th>Born-Wolf</th> <th>JoeMeans</th> </tr> <tr> <td>% Polarization:</td> <td>99.775</td> <td>99.779</td> </tr> <tr> <td>Ellipticity (+RH,-LH):</td> <td>-0.828</td> <td>0.828</td> </tr> <tr> <td>Azimuth Angle:</td> <td>13.288</td> <td></td> </tr> </table>		EIGENVECTORS			EIGENVALUES	-0.087	0.634	0.768	2.18255	0.040	-0.768	0.639	1.49689	0.995	0.087	0.042	0.03896		Born-Wolf	JoeMeans	% Polarization:	99.775	99.779	Ellipticity (+RH,-LH):	-0.828	0.828	Azimuth Angle:	13.288	
RP			IP																																																																																																				
0.0577006	-0.1638372	-0.1065867	0.0000000	0.0841499	-0.1632216																																																																																																		
-0.1638372	1.7616366	0.3287636	-0.0841499	0.0000000	1.7939365																																																																																																		
-0.1065867	0.3287636	1.8990614	0.1632216	-1.7939365	0.0000000																																																																																																		
RP'			IP'																																																																																																				
2.1825457	0.0000001	-0.0000000	0.0000000	-1.8032761	-0.0003891																																																																																																		
0.0000001	1.4968913	-0.0000000	1.8032761	0.0000000	-0.0113041																																																																																																		
-0.0000000	-0.0000000	0.0389624	0.0003891	0.0113041	0.0000000																																																																																																		
RM'			IM'																																																																																																				
2.1462443	0.1533551	-0.0130047	0.0000001	1.8033111	-0.0000000																																																																																																		
0.1533552	1.5331080	-0.0033946	-1.8033111	0.0000000	0.0000000																																																																																																		
-0.0130047	-0.0033946	0.0390467	0.0000000	0.0000000	-0.0000000																																																																																																		
EIGENVECTORS			EIGENVALUES																																																																																																				
-0.087	0.634	0.768	2.18255																																																																																																				
0.040	-0.768	0.639	1.49689																																																																																																				
0.995	0.087	0.042	0.03896																																																																																																				
	Born-Wolf	JoeMeans																																																																																																					
% Polarization:	99.775	99.779																																																																																																					
Ellipticity (+RH,-LH):	-0.828	0.828																																																																																																					
Azimuth Angle:	13.288																																																																																																						
<p>FILE: /data/BX_examples/1oBshock10385</p>		<p>Time Mark: 08 APR 09 11:30:16</p>																																																																																																					

(Select Frequency) (Upgrade) (Print) (Save) (Dismiss)
 POWER SPECTRAL ANALYSIS

- Wave analysis uses the cospectrum and quaspectrum to learn useful things about the wave
- It needs the average field for reference. Detrend but do not subtract the average field
- The first time called “wave Analysis” averages over the entire spectrum. Select a frequency band for the most useful results
- Sometimes analysis of the cospectrum and quaspectrum can give a useful consistency check

Hodograms



- Hodograms can be very informative about the nature of a signal if the signal is two dimensional or deviates simply from a two dimensional behavior
- Select hodograms from the display pull down menu and then select a particular hodogram (A, B, C,...)
- Select a time interval. You may remove the average from the display but usually it is better not to remove the average before first plotting it because the background field provides useful information on the handedness of the wave